





MECHANICAL UNITS

TAV. 1	Crankcase	TAV. 31	Outside Gearbox Controls
TAV. 2	Driving Shaft – Connecting Rods and Pistons	TAV. 32	Engine / Gearbox Connecting Tube and Insulation
TAV. 3	R.H. Cylinder Head	TAV. 33	Differential and Axle Shaft
TAV. 4	L.H. Cylinder Head	TAV. 34	Brake and Clutch Hydraulic System
TAV. 5	Timing – Tappets and Shafts	TAV. 35	Electronic Accelerator Pedal
TAV. 6	Timing Controls	TAV. 36	Pedals
TAV. 7	Fuel Supply System	TAV. 37	Clutch Hydraulic Control –Valid for F1–
TAV. 8	Fuel Pump	TAV. 38	Power Unit and Tank – Valid for F1–
TAV. 9	Fuel Tank – Union And Piping	TAV. 39	Brake System – Not for F1–
TAV. 10	Fuel Tank – Insulation and Protection	TAV. 40	Brake System – Valid for F1–
TAV. 11	Antievaporation Device	TAV. 41	Caliper for Front Brake
TAV. 12	Injection Device – Ignition	TAV. 42	Caliper For Rear Brake
TAV. 13	Brake Booster System	TAV. 43	Hand-brake Control
TAV. 14	Secondary Air Pump	TAV. 44	Hydraulic Steering Box
TAV. 15	Air Intake Manifolds	TAV. 45	Oil Tank, Pump and Serpentine for Servosteering
TAV. 16	Air Intake	TAV. 46	Steering Column
TAV. 17	Front Exhaust System	TAV. 47	Front Suspension – Shock Absorber and Brake Disc
TAV. 18	Rear Exhaust System	TAV. 48	Front Suspension – Wishbones and Stabilizer Bar
TAV. 19	Blow-by	TAV. 49	Rear Suspension – Shock Absorber and Brake Disc
TAV. 20	Lubrication System – Tank	TAV. 50	Rear Suspension – Wishbones and Stabilizer Bar
TAV. 21	Oil/Water Pump	TAV. 51	Wheels
TAV. 22	Cooling System – Radiator and Nourice	TAV. 52	Tyres Pressure Control System –Not for J–
TAV. 23	Clutch and Controls – Not for F1–	TAV. 53	Battery
TAV. 24	Clutch and Controls – Valid for F1–	TAV. 54	Alternator, Starting Motor and A.C. Compressor
TAV. 25	Gearbox	TAV. 55	Air Conditioning System – Freon Pipes
TAV. 26	Differential Carrier and Clutch Cooling Radiator	TAV. 56	Air Conditioning System – Water Pipes
TAV. 27	Main Shaft Gears and Clutch Oil Pump	TAV. 57	Evaporator Unit and Controls
TAV. 28	Lay Shaft Gears	TAV. 58	Tools Equipment –Not with Spare Wheel Version–
TAV. 29	Inside Gearbox Controls – Not for F1–	TAV. 59	Documentation and Accessories
TAV. 30	Inside Gearbox Controls – Valid for F1–	TAV. 60	Spare Wheel and Accessories

COACHWORK


- TAV.100 Body - Outer Trims
- TAV.101 Body - Roof
- TAV.102 Roll Bar -Not for USA, CDN and AUS-
- TAV.103 Front Structures and Components
- TAV.104 Central Structures and Components
- TAV.105 Rear Structures and Components
- TAV.106 Flat Floor Pan and Wheelhouses
- TAV.107 Front Bumper
- TAV.108 Rear Bumper
- TAV.109 Engine Compartment Fire-Proof Insulations
- TAV.110 Passengers Compartment Insulations
- TAV.111 Boot Insulation
- TAV.112 Passengers Compartment Upholstery and Carpets
- TAV.113 Roof Panel Upholstery and Accessories
- TAV.114 Boot Upholstery
- TAV.115 Engine Bonnet
- TAV.116 Boot Door and Petrol Cover
- TAV.117 Doors - Frameworks and Coverings
- TAV.118 Doors - Opening Control and Hinges
- TAV.119 Doors - Power Window and Rearview Mirror
- TAV.120 Glasses and Gaskets
- TAV.121 Front Seat and Seat Belts
- TAV.122 Front Seat - Guide and Movement
- TAV.123 Front Racing Seat - Guide and Movement -Not for USA and CDN-
- TAV.124 Tunnel - Framework and Accessories
- TAV.125 Inner Trims
- TAV.126 Dashboards
- TAV.127 Dashboards Drawer
- TAV.128 Air Bag
- TAV.129 Instruments
- TAV.130 Front and Rear Lights
- TAV.131 Outside Finishings
- TAV.132 Electrical System
- TAV.133 Movement Sensors
- TAV.134 Motor Compartments Control Stations
- TAV.135 Passengers Compartment Control Stations
- TAV.136 Trunk Bottom Control Stations
- TAV.137 Anti-theft Electrical Boards and Devices
- TAV.138 Stereo Equipment
- TAV.139 Windshield, Glass Washer and Horns
- TAV.140 Stickers and Labels

Ricambi > 0001 - CRANKCASE




▲=1


Ricambi > 0002 - DRIVING SHAFT - CONNECTING RODS AND PISTONS




Ricambi > 0003 - R.H. CYLINDER HEAD




Ricambi > 0004 - L.H. CYLINDER HEAD




Ricambi > 0005 - TIMING - TAPPETS AND SHAFTS




Ricambi > 0006 - TIMING - CONTROLS







Ricambi > 0008 - FUEL PUMP




Ricambi > 0009 - FUEL TANK - UNION AND PIPING



Ricambi > 0010 - FUEL TANK -INSULATION AND PROTECTION




Ricambi > 0011 - ANTIEVAPORATION DEVICE




Vale per USA e CDN
Valid for USA and CDN

Ricambi > 0012 - INJECTION DEVICE - IGNITION




Ricambi > 0013 - BRAKE BOOSTER SYSTEM




Modello: 599 GTB Fiorano

Versione: Europa


Ricambi > 0014 - SECONDARY AIR PUMP




Ricambi > 0015 - AIR INTAKE MANIFOLDS




Ricambi > 0016 - AIR INTAKE




Ricambi > 0017 - FRONT EXHAUST SYSTEM




Ricambi > 0018 - REAR EXHAUST SYSTEM




Ricambi > 0019 - BLOW-BY




Soluzione superata
Old solution




Ricambi > 0020 - LUBRICATION SYSTEM - TANK




Ricambi > 0021 - OIL / WATER PUMP




Ricambi > 0022 - COOLING SYSTEM - RADIATOR AND NOURICE





Ricambi > 0023 - CLUTCH AND CONTROLS -Not for F1-




Ricambi > 0024 - CLUTCH AND CONTROLS -Valid for F1-




Soluzione superata
Old solution



Ricambi > 0025 - GEARBOX




Ricambi > 0026 - DIFFERENTIAL CARRIER AND CLUTCH COOLING RADIATOR




Per la sostituzione del differenziale
vedere anche tavola 33
For replacement of differential
see also table 33


Ricambi > 0027 - MAIN SHAFT GEARS AND CLUTCH OIL PUMP




Ricambi > 0028 - LAY SHAFT GEARS




Ricambi > 0029 - INSIDE GEARBOX CONTROLS -Not for F1-




Ricambi > 0030 - INSIDE GEARBOX CONTROLS -Valid for F1-




Ricambi > 0031 - OUTSIDE GEARBOX CONTROLS




Ricambi > 0032 - ENGINE/GEARBOX CONNECTING TUBE AND INSULATION





Ricambi > 0033 - DIFFERENTIAL AND AXLE SHAFT



Ricambi > 0034 - BRAKE AND CLUTCH HYDRAULIC SYSTEM




Ricambi > 0035 - ELECTRONIC ACCELERATOR PEDAL



Vale per GD
Valid for GD





Ricambi > 0036 - PEDALS




Versione con cambio meccanico
Mechanical transmission version

Ricambi > 0037 - F1 CLUTCH HYDRAULIC CONTROL -Valid for F1-







Ricambi > 0039 - BRAKE SYSTEM -Not for GD-



Ricambi > 0040 - BRAKE SYSTEM -Valid for GD-




Ricambi > 0041 - CALIPER FOR FRONT BRAKE




Modello: 599 GTB Fiorano

Versione: Europa


Ricambi > 0042 - CALIPER FOR REAR BRAKE




Ricambi > 0043 - HAND-BRAKE CONTROL




Ricambi > 0044 - HYDRAULIC STEERING BOX





Ricambi > 0045 - OIL TANK, PUMP AND SERPENTINE FOR SERVOSTEERING




Vale fino all'Ass.Nr. 69465
Valid till Ass.Nr. 69465




Vale per GD
Valid for GD




Ricambi > 0046 - STEERING COLUMN




No per F1
Not for F1






Ricambi > 0048 - FRONT SUSPENSION - WISHBONES AND STABILIZER BAR




Modello: 599 GTB Fiorano

Versione: Europa


Ricambi > 0049 - REAR SUSPENSION - SHOCK ABSORBER AND BRAKE DISC




Ricambi > 0050 - REAR SUSPENSION - WISHBONES AND STABILIZER BAR




Ricambi > 0051 - WHEELS







Ricambi > 0053 - BATTERY



Ricambi > 0054 - ALTERNATOR, STARTING MOTOR AND A.C. COMPRESSOR




Vale fino...vedi descrizione
Valid till...see description






Vale fino...vedi descrizione
Valid till...see description


Ricambi > 0055 - AIR CONDITIONING SYSTEM - FREON PIPES




Ricambi > 0056 - AIR CONDITIONING SYSTEM - WATER PIPES




Ricambi > 0057 - EVAPORATOR UNIT AND CONTROLS












Ricambi > 0059 - DOCUMENTATION AND ACCESSORIES




Ricambi > 0060 - SPARE WHEEL AND ACCESSORIES



Ricambi > 0100 - BODY - OUTER TRIMS




Ricambi > 0101 - BODY - ROOF




Modello: 599 GTB Fiorano

Versione: Europa


Ricambi > 0102 - ROLL BAR -Not for USA, CDN and AUS-




Ricambi > 0103 - FRONT STRUCTURES AND COMPONENTS




Ricambi > 0104 - CENTRAL STRUCTURES AND COMPONENTS




Ricambi > 0105 - REAR STRUCTURES AND COMPONENTS




Ricambi > 0106 - FLAT FLOOR PAN AND WHEELHOUSES



Ricambi > 0107 - FRONT BUMPER




Ricambi > 0108 - REAR BUMPER






Sensori di parcheggio
Parking sensors


Ricambi > 0109 - ENGINE COMPARTMENT FIRE-PROOF INSULATIONS




Vale per GD
Valid for GD



Ricambi > 0110 - PASSENGERS COMPARTMENT INSULATIONS




Ricambi > 0111 - BOOT INSULATION





Modello: 599 GTB Fiorano

Versione: Europa


Ricambi > 0112 - PASSENGERS COMPARTMENT UPHOLSTERY AND CARPETS




Ricambi > 0113 - ROOF PANEL UPHOLSTERY AND ACCESORIES




Ricambi > 0114 - BOOT UPHOLSTERY




VERSIONE CON RUOTA DI SCORTA
SPARE WHEEL VERSION



Ricambi > 0115 - ENGINE BONNET





Ricambi > 0116 - BOOT DOOR AND PETROL COVER




Vale per USA e CDN
Valid for USA and CDN


Ricambi > 0117 - DOORS - FRAMEWORK AND COVERINGS




Ricambi > 0118 - DOORS - OPENING CONTROL AND HINGES








Ricambi > 0119 - DOORS - POWER WINDOW AND REARVIEW MIRROR




Ricambi > 0120 - GLASSES AND GASKETS




Ricambi > 0121 - FRONT SEAT AND SEAT BELTS







CINTURE DI SICUREZZA 4 PUNTI
4 POINT SAFETY BELTS




Ricambi > 0124 - TUNNEL - FRAMEWORK AND ACCESSORIES




No per F1
Not for F1












Ricambi > 0126 - DASHBOARD




Ricambi > 0127 - DASHBOARD DRAWER




Soluzione superata
Old solution



Ricambi > 0128 - AIR-BAG




Ricambi > 0129 - INSTRUMENTS




No per F1
Not for F1


Ricambi > 0130 - FRONT AND REAR LIGHTS




Ricambi > 0131 - OUTSIDE FINISHINGS





Ricambi > 0132 - ELECTRICAL SYSTEM




Ricambi > 0133 - MOVEMENT SENSORS




Ricambi > 0134 - MOTOR COMPARTMENTS CONTROL STATIONS






Vale per GB
Valid for GB




Ricambi > 0135 - PASSENGERS COMPARTMENT CONTROL STATIONS




Ricambi > 0136 - TRUNK BOTTOM CONTROL STATIONS




Ricambi > 0137 - ANTI-THEFT ELECTRICAL BOARDS AND DEVICES




Vedi tavola 113
See table 113




Vale per GB
Valid for GB




Vedi tavola 134
See table 134



Ricambi > 0138 - STEREO EQUIPMENT



Ricambi > 0139 - WINDSHIELD, GLASS WASHER AND HORNS



Ricambi > 0140 - STICKERS AND LABELS

